

Tekloom® Graffiti-Proof Upholstery Textiles

Care and Cleaning Instructions

W-S: Clean with either a water-or solvent-based cleaning agent

REGULAR MAINTENANCE

While Tekloom is inherently stain resistant, it is important to keep it clean at all times to maintain the original look and feel. It is important to vacuum upholstery regularly to remove loose dirt and surface dust that builds up, before it becomes embedded in the fibers. Use a soft brush to loosen and brush away surface dirt, followed by vacuuming with an upholstery attachment. Spot cleaning with a clean, soft towel with clean water will remove most everyday stains. Mild soap and water can be used for waterbased stains. A dry cleaning solvent can be used for oil-based stains. General soiling can be removed with a solvent-compatible spray extraction appliance. Periodically, a professional cleaner should thoroughly clean the upholstery to remove the soiling that a normal vacuum cleaner cannot reach.

DISINFECTION

This product can be disinfected with a 1:10 dilution of bleach/water. Apply the solution using a misting spray bottle and gently scrub the affected area with a sponge or soft bristle brush. Allow the mixture to linger for the time specified by the Center for Disease Control and Prevention. **Avoid soaking the seamed area to prevent the bleach from penetrating thru the protective layer.** Rinse with clean water and wipe with a soft cloth. Residue left by bleach will degrade and shorten the life and/or affect the product's appearance if not removed.

APPROVED CLEANERS/DISINFECTANTS

The following list represents some of the most common cleaning and disinfecting agents used in healthcare environments, which have been lab-tested on Tekloom upholstery.* Tekloom protects the woven fabric with a patented, clear Thermoplastic elastomer (TPE) layer. All approved cleaning chemicals should stay on the surface. Avoid soaking seamed areas to prevent the cleaning chemicals from entering the base fabric or the foam underneath.

3M™ C. Diff Solution Tablets	Oxivir® 1 RTU
3M™ Neutral Quat Disinfectant Cleaner Concentrate 23H	Oxivir® Five 16 Disinfectant
3M™ Neutral Quat Disinfectant Cleaner Concentrate 23L	Oxivir® Plus Disinfectant Cleaner
3M™ HB Quat Disinfectant 25L	Oxivir® Tb Wipes
Amphyl® Disinfectant Cleaner	OxyCide™ Daily Disinfectant Cleaner
CaviCide™ Disinfectant Cleaner	Perisept Sporidical Disinfectant Cleaner
CaviWipes™ XL	Sani-Cloth® AF3 Germicidal Disposable Wipes
Clorox Healthcare® Hydrogen Peroxide Wipes	Steris Coverage® Spray HB Plus
Ecolab® A-456 II Disinfectant Cleaner	Stride® Fragrance Free SC Neutral Cleaner
Ecolab® Neutral Disinfectant Cleaner	Virex® II 256 Disinfectant Cleaner
Formula 409®	Virex® Plus One Step Disinfectant Cleaner
Hydrogen Peroxide	Wex-Cide 128 Germicidal Detergent
Lysol® Disinfectant Spray	

* The cleaning recommendations above are just a guide and intended to help the maintenance of the specified product. Wolf-Gordon neither guarantees, nor will take any responsibility for, the specific results, as testing of these products was conducted under laboratory conditions and results may vary under actual conditions.

NOTE: Wolf-Gordon is not liable for any intentional stains, and the damage resulting from lack of cleaning, the misuse of the cleaning agents, or the use of inappropriate cleaning agents on the product. Under no circumstance, shall Wolf-Gordon be liable for any incidental, consequential, or other damage resulting from negligence, misuse, mishandling or exposure to any of the chemicals used in conjunction with the cleaning/maintenance of the product.